

electro-harmonix

DOUBLE ANNIVERSARY BIG MUFF PI

Congratulations on your purchase of the **DOUBLE ANNIVERSARY ELECTRO-HARMONIX BIG MUFF PI** fuzz pedal! This commemorative Muff is inspired by the rich history of the Big Muff Pi and Electro-Harmonix, with design elements that pay homage to the many faces of the Big Muff Pi. The Double Anniversary Big Muff Pi's limited-edition, laser-etched, golden chassis you now hold in your hands houses the sweet singing sustain of our most coveted violet Ram's Head circuit.

CONTROLS AND CONNECTIONS

VOLUME Knob – Sets the output level.

TONE Knob – Provides a range of sounds from high treble to deep bass. As you turn the knob clockwise the treble increases and bass decreases.

SUSTAIN Knob – Adjusts the amount of sustain and distortion.

Footswitch & Status LED – Use the footswitch to toggle between effect and bypass. The device is active when the LED is lit. When the LED is off, the pedal is in true bypass.

INPUT Jack – Plug the output of your instrument or another effects pedal into the ¼" INPUT jack. The input impedance presented at this jack is 117kΩ.

AMPLIFIER Jack – Connect the device's ¼" AMPLIFIER jack to the input of your amplifier or another effects pedal. When the device is in bypass, the AMPLIFIER jack is connected directly to the IN jack. The output impedance is 25kΩ.

POWER

The Double Anniversary Big Muff Pi is powered from a 9V battery or you can use an optional 9VDC AC Adapter capable of delivering at least 25mA. We recommend the EH9 9.6DC-200 AC Adapter. The AC Adapter must have a center negative plug that fits a 2.1mm center pin. The pedal has a current draw of approximately 12mA at 9VDC. The external power supply should not exceed 14VDC.

Please Note: Using the wrong adapter or a plug with the wrong polarity may damage your device and void the warranty.

Changing the Battery To change the 9V battery, remove the center screw on the bottom of the device. Take off the battery plate and change the battery. Avoid touching the circuit board while the battery plate is off. Replace the battery plate and screw.

WARRANTY INFORMATION

Please register online at www.ehx.com/product-registration or complete and return the enclosed warranty card within 10 days of purchase. Electro-Harmonix will repair or replace, at its discretion, a product that fails to operate due to defects in materials or workmanship for a period of one year from date of purchase. This applies only to original purchasers who have bought their product from an authorized Electro-Harmonix retailer. Repaired or replaced units will then be warranted for the unexpired portion of the original warranty term.

If you should need to return your unit for service within the warranty period, please contact the appropriate office listed below. Customers outside the regions listed below, please contact EHX Customer Service for information on warranty repairs at info@ehx.com or +1-718-937-8300. USA and Canadian customers: please obtain a **Return Authorization Number (RA#)** from EHX Customer Service before returning your product. With your returned unit, include a written description of the problem as well as your name, address, telephone number, e-mail address, RA# and a copy of your receipt clearly showing the purchase date.

United States & Canada

EHX Customer Service
Electro-Harmonix
c/o New Sensor Corp.
47-50 33rd St.
Long Island City, NY 11101
Tel: 718-937-8300
Email: info@ehx.com

United Kingdom

John Williams
Electro-Harmonix UK
13 Cmwdonkin Terrace
Swansea SA2 0RQ
United Kingdom
Tel: +44 179 247 3258
Email: electroharmonixuk@virginmedia.com

Europe

Musik Elektronik
EHX Repair Center
Ötterichweg 7
D-90411 Nürnberg
Germany
Tel: +49 911 559152
Email: info@musikhof.de

This warranty gives a purchaser specific legal rights. A purchaser may have even greater rights depending upon the laws of the jurisdiction within which the product was purchased.

COMPLIANCE

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment under FCC rules.



The CE logo indicates that this product has been tested and shown to conform with all applicable European Conformity directives.



The WEEE or "trashcan" logo indicates that this product is made up of electronic components that should not be trashed alongside household waste but instead should be recycled by a proper electrical waste facility.