

22500 SOFTWARE UPGRADE INSTRUCTIONS

REQUIRED ITEMS:

- **22500**
- **SD Card**
- **22500 Power Supply**
- **USB Cable or SD Card Reader**

PROCEDURE:

1. Download the data file called ML2UU_xx.bin to your hard drive. This file is included in the zip file that you downloaded or were emailed. The xx number is a number greater than 25.
2. Copy the ML2UU_xx.bin file to the 22500's SD card. Do this by either connecting your 22500 directly to your computer via a USB cable or by ejecting the SD Card from the 22500 and inserting it into a USB Card reader/writer drive and then connect that to your computer.
3. Once the SD Card appears on your computer, copy the ML2UU_xx.bin file to the root directory of your SD Card. Do not place the .bin file in any folders on the SD Card.
4. After the file has been copied to the SD Card, eject or stop the card on your computer. If you were using the 22500 disconnect it from the computer. If you were using an external drive, move the SD Card from the drive to the 22500.
5. For the next few steps we recommend disconnecting the 22500's audio outputs since a loud pop can occur after the update runs. Please do not remove power at any point during the next few steps.
6. While the 22500 is powered up and running, ensure one of the MODE LEDs is blinking. If none of the MODE LEDs are blinking, press and release the MODE knob.
7. Turn the MODE knob until the ERASE LED is blinking.
8. While the ERASE LED is blinking, press and hold the following 4 buttons simultaneously: A REVERSE, A OCTAVE, B REVERSE, and B OCTAVE. Continue holding the 4 buttons until you see the 8 MODE LEDs blink rapidly. You should now see the digits displaying UUxx.
9. While the 8 MODE LEDs are blinking, press and release the MODE knob, now the 8 MODE LEDs should light up solid.
10. Now press and hold the MODE knob for approximately 2 seconds, until you see U displayed. Release the MODE knob.
11. Your 22500 is now upgraded. If you like, you can connect the 22500 to your computer again and delete the .bin file from the SD Card otherwise it will remain on the card.

Upgrading your 22500 software will not erase any loops that are on your SD Card.